



EN

Construction

The kitchen panel is made of durable tempered Float glass with a thickness of 4 mm, resistant to damage and moisture. The eco-friendly print, protected by a special film, ensures vibrant colors and UV resistance. Polished edges enhance safety, while the smooth surface makes cleaning easy. The set includes mounting tape and adhesive for easy installation.

Installation Instructions

1. Clean and degrease the surface where the panel will be mounted.
2. Apply mounting adhesive in small dots at the center of each tape. The double-sided tapes on the back of the panel serve a protective function – do not remove the protective film.
3. Press the panel evenly against the wall.
4. Allow it to dry according to the adhesive manufacturer's instructions.

Maintenance and Cleaning

Clean the kitchen panel with a soft, damp cloth or sponge with mild detergent. Avoid abrasive cleaners, sharp tools, and harsh chemicals that could damage the glass surface or print. Regular wiping will help maintain its aesthetic appearance and durability.

For gas stoves, it is recommended to maintain a minimum distance of 20 cm from the burners to prevent heat damage to the printed layer.

IMPORTANT! Observe safety precautions when using this product.

The product is made of tempered glass – handle it with care to prevent breakage or damage. Do not expose the panel to strong impacts or intense vibrations, as they may weaken its structure. In case of cracks or chips, immediately stop using the product and dispose of it safely. Keep out of reach of children – there is a risk of injury if the panel falls or gets damaged. Failure to follow these guidelines may result in product damage or personal injury.

