



EN

## Construction

The canvas painting is made of high-quality material with a weight of 240 g/m<sup>2</sup> and features a high-resolution digital print. The entire surface is protected with a UV varnish layer, enhancing durability and resistance to fading. The canvas is stretched over a sturdy wooden frame, with printed edges that provide a seamless continuation of the design. The painting comes with a hanging bracket and two screws for attachment, which need to be installed before hanging.

## Before Installation

Before starting the installation, ensure the product is free from visible damage. Choose a wall that is dry, clean, and even. Avoid areas with excessive moisture to ensure the longevity of the product. Visually check how the painting will look on the selected wall. Optionally, mark the mounting points with a pencil for easier installation.

## Step-by-Step Instructions

**1.** Place the painting face down on a stable, soft surface to avoid damaging the canvas or frame. **2.** Attach the hanging bracket to the top edge of the frame, positioning it centrally. Secure it with the provided screws, ensuring it is firmly attached. **3.** Select the spot where the painting will hang. Use a level to ensure the painting will hang straight. Mark the mounting point with a pencil where you will place the hook or nail. **4.** Drill a hole at the marked spot (if required) and insert a wall plug. Then, attach the hook or nail in the prepared location. **5.** Hang the painting by placing the bracket on the hook or nail. Ensure it is stable and evenly positioned.

## How to Clean the Painting?

Use only a soft cloth to clean the frame and canvas. Avoid using abrasive cleaning agents, as they may damage the painting or its frame.

### **IMPORTANT! Take precautions when using the product.**

Ensure the picture is properly mounted on a stable surface. Avoid moisture, direct contact with fire, and high temperatures to prevent damage to the frame or canvas. Protect the picture from impacts, scratches, and contact with sharp objects. Store it in a dry, shaded place, away from children and pets. After use, dispose of the product according to local regulations for wooden and textile materials. Failure to follow these guidelines may result in product damage or user safety hazards.

