



EN Installation Instructions for Stickers

Know Your Material

The stickers are made from an innovative Magic Stick material that is self-adhesive, allowing for easy installation without glue. It does not crack, wrinkle, or wear out during use. The stickers can be easily removed and reapplied without leaving any residue. They are designed for application on doors, refrigerators, or dishwashers – ensure the purchased product is suitable for the intended surface. Choosing the right sticker ensures durability, stability, and an aesthetically pleasing appearance.

Installation Instructions

Wet Method:

1. Prepare a spray bottle with water.
2. Thoroughly clean the surface where the sticker will be applied – remove dust, dirt, and any other debris.
3. Align the sticker with the surface, printed side up. If necessary, trim it with scissors or a utility knife.
4. Generously spray water on the surface where the sticker will be applied.
5. Peel back about 5–10 cm of the backing paper and spray water on the adhesive side of the sticker.
6. Apply the exposed part of the sticker, smoothing it with a squeegee to push out air and water bubbles.
7. Continue peeling back the paper, spraying the adhesive side with water, and applying the sticker while smoothing it with a squeegee.
8. Once finished, remove all air bubbles and dry the surface with a towel.

Dry Method:

1. Thoroughly clean the surface where the sticker will be applied – remove dust and grease stains.
2. If applying the sticker on a vertical surface, start from the top. For horizontal surfaces, it doesn't matter where you begin.
3. Unroll the sticker on a clean, dry surface, printed side up, and inspect its quality.
4. Position the sticker on the surface, peel back about 20 cm of the backing paper, and fold it underneath.
5. Smooth the applied section with a squeegee, pushing out any air bubbles.
6. Finally, smooth out the entire sticker with the squeegee, removing all air bubbles.

How to Take Care of the Sticker?

Clean with a soft, damp cloth. Avoid using strong detergents that could damage the sticker's surface. Avoid direct contact with sharp objects that may scratch the material.

IMPORTANT! Follow safety precautions when using the product.

Do not place the product in areas exposed to direct contact with fire. Keep out of reach of children – risk of swallowing small parts or protective film. In case of material damage (e.g., tears, cracks), stop using the product immediately and dispose of it safely. Dispose of the product after use in accordance with local regulations for plastic materials. Failure to follow these recommendations may result in damage to the product or personal injury.

